



Grease wash for outdoor furniture

Environmentally friendly detergent for wooden, plastic, and Polywood furniture and wooden and composite terraces. Suitable for the removal of oil, grease, pitch, resin, and other difficult and stubborn dirt. The product efficiently removes dirt and does not contain any ingredients which burden the environment. Biodegradable and plant-based.

Instructions:

Test the detergent in an invisible spot first. Spray the detergent onto the surface and allow it to react for a few minutes or longer, depending on how dirty the surface is. Use a brush or cloth if necessary, and rinse off with water.

Contents:

Plant-based soap < 5 %, Nonionic surfactants < 5 %, Sodium carbonate < 5 %.

Volume: 500ml

EAN-barcode: 6416977715894

<https://www.softcare.fi/en/product/grease-wash-for-outdoor-furniture/>